



Watch how to assemble a hive floor on our YouTube channel

HIVE FLOOR

Suitable for National, Commercial, Smith, Langstroth and Dadant Hives.

Kit Consists Of:
1 x Plywood Panel
2 x Side Piece
1 x Back Piece
1 x Entrance Block
1 x Packet 1½" Nails

Essential Tools:
Hammer
Pinchers
Pencil
Sandpaper

N.B: We recommend using Cascamite Waterproof Glue

Advisable Tools:
2' Sash Cramps

ASSEMBLY INSTRUCTIONS:

1. Try the two side pieces on the plywood panel. Varying thickness may make the plywood tight.
2. If they are tight use a piece of sandpaper (wrapped around a block of wood) to gently thin the edge of the plywood panel, by rubbing at a slight angle.
3. Glue one side piece and place level with the front of the floor, (the edge with the cedar lip).
4. Nail into position, so that the nails pass through the middle of the groove in to the plywood (it may be helpful to mark a line on the side piece to indicate the correct spot for nailing).
5. Repeat this operation with the back and then the other side piece. This completes the floor.
6. When the glue is dry it is a good idea to drive a nail into each side piece to prevent the entrance block from being pushed back into the hive when in use.

