



Watch how to assemble a WBC Super/Brood Chamber on our YouTube channel

W.B.C. SUPER/BROOD CHAMBER

Kit Consists Of: 2 x Grooved Piece (A)
2 x Plain Piece (B)
4 x Square Ended Bar
2 x Thin Strip (C)
2 x Runner
1 x Packet 1" & $\frac{3}{4}$ " Nails

Essential Tools: Hammer
Pinchers
Pencil
Ruler

Advisable Tools: 2 x 2' Sash Cramps

ASSEMBLY INSTRUCTIONS:

1. Mark on the outside of (A) the centre of the two grooves (this is to help when nailing later).
2. Take one of the grooved pieces (A) and put some glue in the grooves.
3. Push the two plain pieces (B) into the grooves, making sure that they are level with the bottom of piece (A). Fix on the other piece (A).
4. Nail together and ensure that the box is square (by measuring the two diagonals, which should be equal).
5. Glue the square bars (C and D) in to place, and nail from the inside. The lower bar should be level with the bottom, and the upper bar level with the top of piece (B), as shown in the side view diagram.
6. Make sure that the box is still square.
7. Attach the thin strips (E) to each side as shown, so that the top of these strips are level with the top of piece (A).
8. Finally attach the runners/ castellated spacers using $\frac{3}{4}$ " nails.

