

Apiguard / Shallow Eke Assembly Instructions



Kit consists of:
x4 Eke Bars

Essential tools:

Hammer
Gimp Pins
Wood Glue
Measuring tape

1



Overlap the 4 eke bar.

2



To secure each bar, apply wood glue to all touching surfaces and fasten with a gimp pin. Before the glue sets, measure both diagonals from corner to corner. If the diagonal measurements are unequal, adjust the frame by pushing or pulling on the corners until both measurements are the same, which will make the eke square.

Please note, if you do not have any wood glue, we suggest you apply 2-3 gimp pins per corner to ensure the frame doesn't move.